

SERVICE CHECK LIST - Classic Range Rover EFi & Catalyst Exhaust Emission Control System

	Mileage '000miles			
	6	12	24	48
VEHICLE INTERIOR				
Check condition and security of seats, seat belts, seat belt mountings, seat belt buckles and operation of inertia seat belts		X	X	X
Check operation of electrical/memory/heated and mechanical seats (where applicable)	X	X	X	X
Check operation of foot brake and clutch		X	X	X
Check operation of all lamps, horns and warning indicators		X	X	X
Check operation of front/rear screen wipers and washers and condition of wiper blades		X	X	X
Check security and operation of handbrake	X	X	X	X
Depressurise air suspension system			X	X
Renew compressor air filter			X	X
Remove/refit air reservoir drain plug			X	X
Repressurise air suspension system			X	X
VEHICLE EXTERIOR				
Check/adjust headlamp and auxillary lamp alignment		X	X	X
Check headlamp levelling system		X	X	X
Check front wheel alignment		X	X	X
Remove road wheels	X	X	X	X
Check tyres comply with manufacturers specifications	X	X	X	X
Check tyres visually for cuts, lumps, bulges, uneven treadware and depth and tyre pressure	X	X	X	X
Inspect brake pads for wear, calipers for leaks, and disks for condition	X	X	X	X
Renew fuel filter				X
Refit road wheels to original hub position	X	X	X	X
Check operation of all doors, bonnet and taildoor locks		X	X	X
Lubricate all hinges, door-check mechanisms, bonnet catch and fuel flaps		X	X	X
UNDER BONNET				
Check cooling and heater systems for leaks, hoses for security and condition		X	X	X
Check brake servo hose for security and condition		X	X	X
Check fuel evaporative loss control system for leaks				X
Check fuel filler cap seal for leaks				X
Check PCV system for leaks and hoses for security and condition (Positive crankcase ventilation)			X	X

X indicates items carried out during a standard service. Due to our policy of continuous improvement, the work undertaken on your vehicle service may be altered without prior notification.

SERVICE CHECK LIST - Classic Range Rover EFi & Catalyst Exhaust Emission Control System

	Mileage '000miles			
	6	12	24	48
UNDER BONNET (Continued)				
Clean plenum chamber ventilation passageway. Check and clean PCV system and breathers (Positive crankcase ventilation)			X	X
Renew PCV intake filter, check and clean PCV system (Positive crankcase ventilation)				X
Check/clean air cleaner dump valve and element		X		
Renew air cleaner element, check/clean dump valve			X	X
Clean distributor cap and rotor arm, check for cracks and tracking		X	X	X
Lubricate distributor rotor spindle with rotor arm removed			X	X
Check ignition wiring and H.T. leads for fraying, chafing and deterioration		X	X	X
Clean/adjust spark plugs		X		
Renew spark plugs			X	X
Renew charcoal canister				X
Check engine emission control system hoses, tubes and vacuum lines for security and condition				X
Check operation of electronic control unit/systems				X
Check condition of driving belts, adjust if required	X	X	X	X
Check throttle and automatic transmission cable operation		X	X	X
Check/top up automatic transmission fluid	X	X		
Check/top up cooling system	X	X	X	X
Check/top up fluid in power steering reservoir	X	X	X	X
Check/top up clutch fluid reservoir	X	X	X	X
Check/top up brake fluid reservoir	X	X	X	X
Check/top up windscreen and rear washer reservoir	X	X	X	X
Lubricate accelerator control linkages and pedal pivot		X	X	X
Check/adjust ignition timing			X	X
Check/adjust engine idle speed				X
Check/adjust steering box		X	X	X
Remove battery connections, clean, grease and refit	X	X	X	X
UNDER VEHICLE				
Renew engine oil and filter	X	X	X	X
Renew gearbox oil			X	X
Check/top up gearbox oil	X	X		
Renew automatic transmission fluid and filter			X	X
Renew transfer box oil			X	X

X indicates items carried out during a standard service. Due to our policy of continuous improvement, the work undertaken on your vehicle service may be altered without prior notification.

SERVICE CHECK LIST - Classic Range Rover EFi & Catalyst Exhaust Emission Control System

	Mileage '000miles			
	6	12	24	48
UNDER VEHICLE (Continued)				
Check/top up transfer box oil	X	X		
Renew front axle oil			X	X
Check/top up front axle oil	X	X		
Renew swivel pin housing oil			X	X
Check/top up swivel pin housing oil	X	X		
Renew rear axle oil			X	X
Check/top up rear axle oil	X	X		
Lubricate propeller shaft sliding joints			X	X
Lubricate propeller shaft universal joints		X	X	X
Lubricate handbrake mechanical linkage		X	X	X
Check visually brake, fuel, clutch pipes/unions for chafing, leaks and corrosion		X	X	X
Check exhaust system for leakage, security and damage	X	X	X	X
Renew oxygen sensors				at 48,000miles if required
Check road wheel speed sensor electrical harness for damage (ABS only)	X	X	X	X
Check for fluid leaks from power, manual steering and suspension systems, hydraulic pipes and unions for chafing and corrosion	X	X	X	X
Check/tighten steering unit and steering rod ball joint fixings, check condition of ball joints and dust covers		X	X	X
Check air harness pipes for security and damage		X	X	X
Check air springs for security and damage		X	X	X
Check shock absorbers/height sensors and harness assembly for leakage and damage		X	X	X
Check tightness of propeller shaft coupling bolts		X	X	X
Ensure front and rear axle breathers are free from obstruction		X	X	X
Check/tighten front and rear axle suspension link fixings, check condition of mounting rubbers		X	X	X
Check for oil leaks from engine and transmission		X	X	X
Drain flywheel housing if drain plug is fitted for wading (refit)		X	X	X
Check/tighten fuel tank fixings		X	X	X
Check security of towing bracket		X	X	X
Adjust handbrake if required		X	X	X
Carry out road or roller test	X	X	X	X
Endorse service record and report any additional work required	X	X	X	X

X indicates items carried out during a standard service. Due to our policy of continuous improvement, the work undertaken on your vehicle service may be altered without prior notification.