

SERVICE CHECK LIST - Defender 300TDi

	Mileage '000miles			
	6	12	24	48
VEHICLE INTERIOR				
Check condition and security of seats belts, seat belt mountings, seat belt buckles and operation of inertia seat belts		X	X	X
Check operation of all lamps, horns and warning indicators		X	X	X
Check operation of front/rear wipers and washers and condition of wiper blades		X	X	X
Check operation of handbrake and adjust if required		X	X	X
Remove battery connections, clean, grease and refit			X	X
VEHICLE EXTERIOR				
Check/adjust headlamp and auxillary headlamp alignment		X	X	X
Remove road wheels	X	X	X	X
Check tyres comply with manufacturers specifications	X	X	X	X
Check tyres visually for cuts, lumps, bulges, uneven tread wear and depth and tyre pressure	X	X	X	X
Inspect brake pads for wear, calipers for leaks, and disks for condition	X	X	X	X
Refit road wheels to original hub position	X	X	X	X
Check front wheel alignment		X	X	X
Check operation of all doors, bonnet and taildoor locks		X	X	X
Lubricate all hinges, door check/lock mechanisms, bonnet catches and fuel lid lock	X	X	X	X
UNDER BONNET				
Check cooling, intercooler and heating systems for leaks, hoses for security and condition. Top up as required		X	X	X
Check/adjust valve clearances		X	X	X
Renew fuel filter element		X	X	X
Renew air cleaner element(s) and clean dump valve		X	X	X
Clean engine breather filter		X	X	X
Check condition of driving belts, adjust/renew as required	X	X	X	X
Check/top up fluid in power steering fluid reservoir		X	X	X
Check/top up clutch fluid reservoir		X	X	X
Check/top up brake fluid reservoir		X	X	X
Check/top up windscreen and rear washer reservoir	X	X	X	X

X indicates items carried out during a standard service. Due to our policy of continuous improvement, the work undertaken on your vehicle service may be altered without prior notification.

SERVICE CHECK LIST - Defender 300TDi

	Mileage '000miles			
	6	12	24	48
UNDER BONNET (Continued)				
Lubricate accelerator linkages		X	X	X
Visually check intercooler/radiator for external obstructions		X	X	X
Flush diesel intercooler element				X
UNDER VEHICLE				
Renew engine oil and filter	X	X	X	X
Renew gearbox oil		X	X	X
Renew transfer box oil			X	X
Check/top up transfer box oil		X		
Renew front and rear axle oil			X	X
Check/top up front and rear axle oil		X		
Renew swivel pin housing oil (pre VIN LD104957 vehicles only)			X	X
Check/top up swivel pin housing oil (pre VIN LD104957 only)		X		
Lubricate propeller shaft universal/sliding joints		X	X	X
Visually check brake servo hose, fuel, clutch pipes/unions for chafing, leaks & corrosion. Investigate if necessary	X	X	X	X
Check exhaust system for leaks, security and damage		X	X	X
Check for fluid leaks from power/manual steering & suspension systems, hydraulic pipes and unions for chafing & corrosion	X	X	X	X
Check/tighten steering unit and steering rod ball joint fixings, check condition of all joints and dust covers		X	X	X
Check/tighten front and rear axle suspension link fixings, check condition of mounting rubbers		X	X	X
Drain fuel sedimenter	X	X	X	X
Check security of towing bracket		X	X	X
Carry out road or roller test	X	X	X	X
Endorse service record and report any unusual features of vehicle condition and additional work required	X	X	X	X

X indicates items carried out during a standard service. Due to our policy of continuous improvement, the work undertaken on your vehicle service may be altered without prior notification.